



DERMO COLOR

PIGMENTS FOR LEATHERS

DERMO COLOR set is made up of water-soluble pigments dissolved in a half-viscous emulsion.

Viscous liquid

Characteristic perfume

pH at 20°C 8 - 9

Good solubility in water

Freezing temperature Less than 0°C

Pigments available:

WHITE - BLACK - RED - BLUE - YELLOW - ORANGE - DARK BROWN - CAMEL

DERMO COLOR set has an excellent covering effect and elasticity.

DERMO COLOR set can be easily used with any tool: spray gun, brush or buffer.

DERMO COLOR set has to be used not-diluted or put directly on leather without further additives. To assure the best solidity of the color and to obtain a bright effect, it is advisable to spray a small quantity of a fixing agent on the treated leather that must be well dry.

Since these are basic color pigments, it is understood that they can be mixed together to obtain any desired color tone.

It is advisable to spray outdoors or under exhaust-fan at a temperature of 20-35°C. Use a compressed-air spray gun with a 0.8- 1 mm nozzle (pressure 2 bar).

DERMO COLOR can be stored for 1 year.

The bottle should always be tightly closed after drawing.

Shake before the use.

Plastic bottle with 1 Kg content.

Codes: 747101 to 747801

Our advices contained herein regarding the use of our products provide general information only without ensuring technical properties. Any influence on fabric is subject to self-determination and therefore in the users own responsibility. Our suggestions are to the best of our knowledge and no liability can be derived thereof.